

## Recommend strap pin installation

- It is important not to hit the internal bolts that connect the neck to the body as well as the maple dowels which re-enforce the heel.
- We recommend drilling a pilot hole on the rounded part of the heel 1 3/8" from the rosewood cap as shown in the illustration.
- When inserting the strap pin, do not use a screw that is longer than 1" and never use a power screw-driver.
- You may want to lubricate the screw with wax before inserting it, this will further prevent cracking or splitting of the wood.

Please note that only a qualified guitar technician should install the endpin on your guitar.

- 

